Acoustic Pro™ Fabric Wrapped Panels

ROTOFAST ANCHOR INSTALL INSTRUCTIONS

Rotofast snap-on anchors are a secure, fast way to mount Acoustic Pro™ panels to a wall. This guide walks through each step, from receiving your panels to pushing them into place.

Receiving and Handling

- Carry panels upright, with the width in the vertical position, to avoid stressing the panel and possibly cracking or breaking it.
- Wear disposable white cotton gloves whenever possible to avoid soiling the fabric, especially light-colored fabrics.
- Clean stains and soiling, including adhesive, as soon as possible to make removal easier (see the Acoustic Pro Fabric Cleaning & Disinfection Guide).

Installation Tools

- Rotofast driver tool
- Rotofast snap-on anchors, marking plugs, and ratchets
- #8 screws (recommended)
- Drill or screw gun
- Laser or chalk line
- Plumb bob or laser
- Shims



Rotofast snap-on hardware: anchor, marking plug, ratchet, and driver tool

Planning

- This guide covers mounting Acoustic Pro panels to a wall with Rotofast snap-on anchors.
- Second Skin Audio matches the number of anchors to your panel size and ships the hardware with your order. Use all of the hardware provided.
- On standard panel sizes, anchors typically sit about 4 to 6 inches in from each corner. Questions about placement or quantities? Contact us and we will get you the answer.

Preparation

1. Strike a level line at the panel bottom with a laser or chalk line. Where field conditions and experience call for additional support, leveling clips, bottom angle, or J-trim are recommended.
2. Establish a plumb line for the first panel with a laser or plumb bob. Use it as a reference for the remaining panels.
3. Check that the existing wall is flat and true. Shim the ratchets as needed to provide a flat, plumb panel installation.
4. Mark the top edge of each panel so you know which way is up.

Installation



Step 1

Screw the Rotofast snap-on anchors into the back of the panel using the Rotofast driver tool.



Step 2

Insert a marking plug into each snap-on anchor.



Step 3

Hold the panel in position on the wall, level with your lines, and push it against the wall to mark the anchor locations.



Step 4

Screw a ratchet into the wall at each marked location. #8 screws are recommended. The flat side goes against the wall and the curved side faces out.



Step 5

Firmly push the panel onto the ratchets to complete the installation.

For any other questions or field problems, contact Second Skin Audio at 800-679-8511 or visit www.secondskinaudio.com.