

HEAT WAVE PRO™ JUTE INSULATION

SOUND ABSORBING THERMAL BARRIER INSTALLATION INSTRUCTIONS

INSTALLATION TOOLS

- Utility knife, scissors, or electric fabric cutter
- Adhesive
- Foil tape

PLANNING

- 1 For best results, Heat Wave Pro should be applied on top of a constraint layer damper, like Damplifier Pro or a liquid deadener like Spectrum.
- 2 Heat Wave Pro is a recycled jute pad sandwiched between two sheets of reinforced aluminum foil designed to reduce heat transfer and absorb airborne sound waves.
- 3 Heat Wave Pro is flexible and durable enough to be used just about anywhere (roof, floor, engine compartment, doors, firewall, trunk, hood) in any type of vehicle (car, truck, SUV, van, bus, boat, RV, trailer, semi-truck, tractor).

PREPARATION

- 1 Remove headliner, upholstery, or carpet to expose bare sheet metal.
- 2 Clean up any loose debris, rust, dirt, or waxy oils. Clean the surface with denatured alcohol.



An electric fabric cutter is the easiest way to cut large quantities of Heat Wave Pro.

Always install Heat Wave Pro with a 2" air gap from the heat source.

HEAT WAVE PRO™ JUTE INSULATION

SOUND ABSORBING THERMAL BARRIER INSTALLATION INSTRUCTIONS

INSTALLATION

- 1 Cut Heat Wave Pro to the desired size with a sharp utility knife or scissors. Cut the material to fit with sizes that allow you to reinstall upholstery or trim.
- 2 Do not cover drain holes or mechanical devices.
- 3 Heat Wave Pro can be adhered with spray adhesive or super strong double sided tape.

Spray Adhesive: P329 Spray Adhesive, or 3M 90

- Spray adhesive on both the Heat Wave Pro and the application surface. Wait 1-2 minutes for adhesive to become tacky, and then apply pressure for several minutes to bond the material to the panel.

Super Strong Double Sided Tape

- Apply tape to Heat Wave Pro around the entire perimeter with an "X" across the middle. Apply pressure for several minutes to bond the material to the panel.

- 4 Seal exposed edges and seams with foil tape.
- 5 Factory carpet can be installed immediately. Aftermarket carpet kits that are glued in place can be attached to the top of Heat Wave Pro