

CELLUZORBE™ HD SOUNDPROOFING BACKER

WALL INSTALLATION INSTRUCTIONS

RECEIVING AND HANDLING

These boards should be handled with care. Prior to unpacking, check package for any obvious shipping damage. If no evidence of damage is present, move package to a dry/controlled area and inspect it for dents, breakage, or any lesser-noticeable damage that may affect enclosed panels. If damage has been identified, record it/photograph it, and open to inspect for concealed damage. If damage was transferred to the product, document/photograph the issues.

INSTALLATION TOOLS

- Mechanical fastener of choice: drywall screws or nails (minimum of 1-1/4" long)
- Sharp utility knife or table saw
- 48" Drywall T-Square
- Level
- Acoustic caulk for seams and edges

PLANNING

- 1 Measure the width and height of the wall. CelluZorbe HD is to be installed vertically (if possible) along studs prior to installation of gypsum drywall. Along the height, make note of how much material will be needed as partial panels.
- 2 When cuts are necessary make a straight cut using a sharp utility knife or table saw and a T-square.

INSTALLATION

- 1 Attach CelluZorbe HD to the studs using drywall screws or nails with one fastener in each corner and one in the middle of the two along each stud. Fasteners must be long enough to penetrate the board and the stud by at least 3/4".
- 2 Finish securing CelluZorbe HD on the studs and across the bottom plate, butting the edges up to each other at the center of the stud. If you are up to 1/4" short of the bottom, seal with acoustical sealant.
- 3 Make cutouts for any outlets, light switches, or other penetrations. Apply pressure to find the outlet, and then cut around with a utility knife.
- 4 Install your 5/8" drywall to the wall horizontally (if possible). Seal around the perimeter of your drywall and any penetrations (outlets, etc) with acoustical sealant.

CELLUZORBE™ HD SOUNDPROOFING BACKER

WALL INSTALLATION INSTRUCTIONS

