

LUXURY LINER™ MASS LOADED VINYL ROLL

WALL INSTALLATION INSTRUCTIONS

RECEIVING AND HANDLING

Luxury Liner™ Mass Loaded Vinyl should be stored indoors until ready to use. These rolls are very heavy, so be sure to have assistance when moving or installing the MLV.

INSTALLATION TOOLS

- Mechanical fastener of choice: nails, staples, or screws (with washers)
- Sharp utility knife, or sharp shears (sharp!)
- 48" Drywall T-Square
- Level
- Acoustic caulk and foil tape for seams and edges

HOW TO INSTALL

- 1 Measure the height of the wall from top to bottom and roll out the MLV so the length of the material matches the wall's height. Mark the MLV. Make a straight cut using a sharp utility knife and a T-square.
- 2 Fasten the MLV to the wood top plate using staples, screws, or nails. If using a pneumatic stapler, staple every 6". For nails or screws with washers, fasteners every 12-16". Attach securely and at the top before allowing MLV to hang.
- 4 Finish securing MLV with additional fasteners on the studs and across the bottom plate. If the MLV hangs long, cut it to flush. If you are up to 1/4" short, seal the bottom with acoustical sealant.
- 4 Make cutouts for any outlets, light switches, or other penetrations. Apply pressure to find the outlet, and then cut around with a utility knife.
- 5 Butt edges side-by-side at the center of the stud. Tape the seam. If MLV seams do not meet at a stud, then overlap the MLV by 2" and seal with foil tape.
- 6 Confirm your MLV is flush before installing drywall. Add 5/8" drywall to the wall. Seal around the perimeter of your drywall and any penetrations (outlets, etc) with acoustical sealant.



If you overlap MLV on the studs, then it will push out and bow the drywall. Only overlap MLV edges if the seams meet in a gap between studs!

If you make any accidental cuts in your MLV, seal those cuts with foil tape.