

# MELA MUTET™ ACOUSTIC FOAM PANELS

## CONSTRUCTION ADHESIVE INSTALLATION INSTRUCTIONS

### RECEIVING AND HANDLING

Prior to unpacking, check package for any obvious shipping damage. If no evidence of damage is present, move package to a dry/controlled area and inspect it for any lesser-noticeable damage. If damage has been identified, record it/photograph it, and open to inspect for concealed damage. Wear gloves when handling the foam, and handle with care at all times to avoid damage to the material. Do not twist or bow the foam during installation.

### INSTALLATION TOOLS

- Construction adhesive for painted or concrete substrate (Loctite Power Grab, Liquid Nails, or equivalent)
- 48" Drywall T-Square
- Level

### HOW TO INSTALL

- 1 Measure and mark the distance on the top and one side of the foam where it is to be placed on the wall or ceiling.
- 2 Make a horizontal and vertical line so they intersect to form a corner. A level is recommended.
- 3 Cut the nozzle of the recommended construction adhesive cartridge so that a ¼" bead of adhesive can be applied.
- 4 Apply construction adhesive evenly in an X-pattern and then around the outside edge. Leave at least 1" of space along the edges.
- 5 Align the panel edges to the side vertical and top horizontal lines, matching the corner of the foam panel to the corner drawn on the substrate.
- 6 Gently press the material and substrates together, and avoid crushing the protruding pieces.



Wear gloves when handling foam, and handle with care.

( CONTINUED ON NEXT PAGE )

# MELA MUTET™ ACOUSTIC FOAM PANELS

## CONSTRUCTION ADHESIVE INSTALLATION INSTRUCTIONS

