

MELA MUTET™ ACOUSTIC FOAM CORNER BASS TRAP

P329 SPRAY ADHESIVE INSTALLATION INSTRUCTIONS

RECEIVING AND HANDLING

Prior to unpacking, check package for any obvious shipping damage. If no evidence of damage is present, move package to a dry/controlled area and inspect it for any lesser-noticeable damage. If damage has been identified, record it/photograph it, and open to inspect for concealed damage. Wear gloves when handling the foam, and handle with care at all times to avoid damage to the material. Do not twist or bow the foam during installation.

INSTALLATION TOOLS

- P329 spray adhesive
- 48" Drywall T-Square
- Level

HOW TO INSTALL

- 1 Measure and mark the distance on the top and one side of the foam where it is to be placed on the wall or ceiling.
- 2 Make a horizontal and vertical line so they intersect to form a corner. A level is recommended.
- 3 Apply P329 spray adhesive with 80 to 100% coverage to both flat sides of the material and both substrates. To avoid overspray, leave a small 1" gap around the edge of the foam.
- 4 Allow 2-4 minutes for the spray adhesive to tack up.
- 5 Gently press the material and substrates together toward the corner, and avoid crushing the protruding pieces.



Wear gloves when handling foam.

The P329 spray canister system should be sprayed at over 60°F. If the canister gets abnormally chilled or freezes, warm it up by immersing in warm water. Do not store at temperatures over 120°F.

(CONTINUED ON NEXT PAGE)

MELA MUTET™ ACOUSTIC FOAM CORNER BASS TRAP

P329 SPRAY ADHESIVE INSTALLATION INSTRUCTIONS

