

POLYZORBET™ POLYESTER ACOUSTIC BAFFLES

HANGING INSTALLATION INSTRUCTIONS

RECEIVING AND HANDLING

Prior to unpacking, check package for any obvious shipping damage. If no evidence of damage is present, move package to a dry/controlled area and inspect it for any lesser-noticeable damage. If damage has been identified, record it/photograph it, and open to inspect for concealed damage.

INSTALLATION TOOLS

- Corkscrew hangers (provided)
- Hot glue gun
- Light duty cable or chains
- Cable clamps
- Level

HOW TO INSTALL

- 1 Choose which edge you will mount on (for portrait or landscape orientation). Measure out at least 3" in from the edge of the baffle and center along the thickness of the baffle. Mark that point. Repeat on the other edge.
- 2 Using the provided corkscrew hanger, screw into the panel about halfway and then unscrew carefully. Apply hot glue to the newly created hole.
- 3 Screw in the corkscrew until only the eyelet is visible. Apply light downward pressure as you screw in the corkscrew. Eyelet should be parallel with the edge of the baffle.
- 4 Repeat steps on the other edge of the baffle.
- 5 Loop suspension cable (provided by other) into the eyelet on the corkscrew and close the loop with a cable clamp or similar hardware.
- 6 Anchor the suspension cable to the roof deck or ceiling structure. Use level to ensure an even hang.



If the corkscrew is crooked or comes through the side, start with a fresh hole and be sure to match the other edge symmetrically.

(CONTINUED ON NEXT PAGE)

POLYZORBET™ POLYESTER ACOUSTIC BAFFLES

HANGING INSTALLATION INSTRUCTIONS

