

POLYZORBET™ POLYESTER ACOUSTIC CLOUDS

HANGING INSTALLATION INSTRUCTIONS

RECEIVING AND HANDLING

Prior to unpacking, check package for any obvious shipping damage. If no evidence of damage is present, move package to a dry/controlled area and inspect it for any lesser-noticeable damage. If damage has been identified, record it/photograph it, and open to inspect for concealed damage.

INSTALLATION TOOLS

- Corkscrew hangers (provided)
- Hot glue gun
- Light duty cable or chains
- Cable clamps
- Level

HOW TO INSTALL

- 1 Measure out at least 4" in from each corner. Mark the spot and repeat for all four corners.
- 2 For a 1/2" panel, cut the provided corkscrews about 2-1/4 turns down using metal snips before proceeding.
- 3 Using the corkscrew hanger, screw into the panel about halfway and then unscrew carefully. Apply hot glue to the newly created hole.
- 4 Screw in each corkscrew until only the eyelet is visible. Apply light downward pressure as you screw in the corkscrew. Don't poke through the other side. Eyelet should be parallel with the edge of the cloud.
- 5 Loop suspension cable (provided by other) into the eyelet on the corkscrew and close the loop with a cable clamp or similar hardware.
- 6 Anchor the suspension cable to the roof deck or ceiling structure. Use level to ensure an even hang.



For multiple installations, creating a cardboard template with cutout holes can help speed up the overall process.

If the corkscrew is crooked or comes through the other side, start with a fresh hole and be sure to match the other edges symmetrically.

(CONTINUED ON NEXT PAGE)

POLYZORBET™ POLYESTER ACOUSTIC CLOUDS

HANGING INSTALLATION INSTRUCTIONS

