

THE STOMP ROLL RUBBER FLOORING

CLEANING & MAINTENANCE INSTRUCTIONS

CLEANING MATERIALS

- Shop vac with soft bristle
- Soft nylon brush, microfiber mop, or 3M 5100 Red Pad
- Soap & water or mild detergent
- Stiff decking brush, car washing brush, 3M 7100 Brown Pad, or 3M 7200 Black Pad (heavy duty cleaning only)



- Do not clean rubber flooring with any kind of solvent. Paint thinners or other “hot” products will eat at the binder and damage the rubber flooring.

INITIAL CLEANING PROCEDURE

1. Remove all surface soil, debris, sand, and grit by sweeping, dust mopping, or vacuuming.
2. Clean floor with soap & water using a rectangular microfiber mop. A soft nylon brush may be used in heavily soiled areas.
3. DO NOT flood the floor with water, as water can pass through any seams.

REGULAR MAINTENANCE CLEANING

1. Remove all surface soil, debris, sand, and grit by sweeping, dust mopping, or vacuuming.
2. Clean floor with soap & water using a rectangular microfiber mop. A soft nylon brush may be used in heavily soiled areas.

HEAVY DUTY CLEANING

1. Remove loose soil, debris, sand, and grit by sweeping or vacuuming
2. Scrub affected areas using a stiff decking brush or car washing brush and soap & water. Alternatively, a rotary scrubber or automatic scrubber can be used with a 3M 7100 Brown Pad or 3M 7200 Black Pad.
3. Rinse with clean water. Do not flood the floor.
4. Allow floor to thoroughly dry.